

How do I Add an Operator?

- In IVIS Plus go to Modules >> Security.
- Click “Add”.
- Input the Username and Password (case sensitive) and click OK.
- Click on the new Username that you just created.
- Click “Access”.
- Click on either “Full”, “Read Only”, or indicate the areas of access you wish the operator to have.