

I attempt to take a picture and get: CAM_COMM_PORT_NOT_AVAILABLE.

This means that the [digital camera](#) is not connected to the system. You may need to connect the [camera cable](#) to the camera. If it is secure, then you may need to connect the cable to the computer system's [communications port](#).

If this is all intact, there may be broken pins on the male end of the camera cable, or you may have a bad port on your computer.